AR Dorsal LRD w/Delta Link A Fall Arrest E Limited Access D Suspension & Controlled Descent Ladder Access Positioning R Rescue Visual Indicator


CLASS III ONE PIECE HARNESS LOT & DATE OF MFO

Fall Safe **Harness**

Manufactured from custom made webbing to offer a lightweight, durable harness. A resin bond agent has been added to the webbing to increase wear and durability. Universally sized for a wide range of workers. Rear D ring pad prevents D ring from sliding and will not break if worker is lowered on it. Stab-Lock quick connect leg buckles for easy doning. Comes equipped with sub-pelvic strap. Sternal attachment loops can be connected with delta link (provided) for use in work positioning, ladder climbing, emergency descent control and rescue applications. Weight 2 lb. 14 oz.

- ANSI/ASSP Z359.11 for full body harnesses

• One size, fully adjustable and XL • Shoulder D rings available at \$10 charge • Optional leg pads available (item 413) Optional shoulder pads available (item 411) • UL Certified for NFPA 2500-2022 for Class III harness and · Meets ANSI, OSHA 1910 and 1926 full body harness stan-





2608 Hartnell

Yates

Gear

Inc.

Phone Phone,

/Fax

1 Ave. Suite 6, F (800-Yates-16 ()-222-4606 Fax

, Redding, C*l* 5 (800-928-ax 530-222-

8-3716)

CA.

96002

www.yatesgear.com



Yates Gear Inc. warrants for one year from the purchase date and only to the original retail buyer that our products are free from defects in material and workmanship. If the buyer discovers a warranty related defect, the buyer should return the product to Yates Gear Inc. Yates Gear Inc. reserves the option to repair or replace any product returned under warranty. That is the extent of our liability under this warranty and, upon the expiration of the applicable warranty period, all such liability shall terminate. Warranty Exclusions

36

Ò

Fall S

Harness

Yates Gear Inc. does not warrant products against a modification or alteration, improper use, improper magence, damage, or if the product is used for a purpose warranty gives you specific legal rights, and you ma from state to state. Except as expressly stated in this valiable for direct, indirect, incidental, or other types of from the use of the product. Warning s against normal wear and tear, unauthorized aproper maintenance, accident, misuse, neglira proper maintenance, accident, misuse, neglira proper for which it was not designed. This not you may also have other rights which vary ed in this warranty, Yates Gear Inc. shall not be types of damages arising out of, or resulting

Products manufactured by Yates Gear Inc. are intended for use by professionals trained and experienced in the use, inspection, and maintenance of these products. Many products which Yates manufactures are used in high angle environments which pose a very substantial risk of serious injury or death. You must read and understand all of the manufacturer's instructions before use. Any person purchasing this equipment assumes the responsibility for seeking proper training in its use. Purchaser also assumes all risk for any injury or damage sustained while using any of this equipment. Failure to follow these warnings increases the risk of injury and death. it is separated

It is suggested that the user refer to of the harness/belt. Keep this user instructions/information sheet as a permanent record after from the harness/belt, and make a copy to be kept with the harness/belt. It is suggested that the user refer to this user information sheet before and and after each use

Use caution when using this equipment around moving machinery, sharp edges, chemical hazards and high heat environment or flame. Car where it will be protected as the harness/belt could melt or burn and fail or high temperature. Do not alter or intentionally misuse this harness in any way. Any alterations or repairs to this harness should be conducted by the manufacturer only. ery, electrical hazards, e. Carry the harness/belt d fail if exposed to flame

sheet has been prepared in accordance with the requirements of NFPA 2500/2022

If you have any questions concerning the condition of your harness/belt, or have any doubt about putting it into service contact manufacturer.





ALWAYS USE SELF CLOSING SELF LOCKING CONNECTORS PERSONAL FALL ARREST AND RESCUE SYSTEMS SHOULD **ONLY** BE ATTACHED TO D-RING LOCATED ON BACK OF HARNESS BETWEEN SHOULDERS A: FALL ARREST R: RESCUE ALL OTHER D-RINGS ON HARNESS ARE FOR APPLICABLE CONNECTIONS L: LADDER CLIMBING (IF PRESENT) D: DESCENT CONTROL (IF PRESENT) P: WORK POSITIONING (IF PRESENT)

s only within the capacity ra

366 Fall Safe Harness

Designed for use as a full body harness per the requirements set forth in ANSI/ASSP Z359.11-2021. UL Certified to meet the harness requirements of NFPA 2500, Standard for Operations and Training for Technical Search and Rescue Incidents and Life Safety Rope and Equipment for Emergency Services, Edition 2022; Class III full body harness and ANSI/ASSP Z359.11-2021 Safety Requirements for Full Body Harnesses.

Usage and Applications

Use only with compatible components (e.g., connectors, lanyards, and energy absorbing lanyards) as part of a complete personal fall protection system. ANSI Z359 compliant components and systems are recommended. D ring located in the rear between the shoulders (dorsal) as well as sternal D ring should be used for all fall arrest applications. Free fall distance should be minimized for all fall arrest applications. Maximum free fall distance is dictated by type of fall protection lanyard or system utilized. Ensure complete inspection and appropriate verification of fall protection system prior to use.

See supplied information sheet for attachment of chest ascender for rope ascending.

Maximum capacity of harness is 310 lbs. per ANSI/ASSP Z359.11-2021

Before Use

The techniques employed in the proper and safe use of this equipment may only be learned through *personal* instruction received from an instructor who is well-qualified in all phases of work at height. Such instruction will include an evaluation of your comprehension of, and ability to perform, the tasks required to safely and efficiently use this equipment. Never attempt use until you have received such instruction and are believed competent by your instructor.

Donning and Fitting the Harness

First inspect entire harness: see section Maintenance, Service, Storage Step 1: Locate black rear fall arrest D ring located on rear of harness. Hold harness up by this D ring and ensure that the straps are not twisted.

Step 2: Disconnect Stab-Lock buckles located at sternum and legs. Disconnect chest delta link.

Step 3: Put harness on like you are donning a jacket. Allow harness to slide down over body. Large D ring should be located on your back between shoulder blades.

Step 4: Make certain straps are not tangled and hang freely. Connect chest/sternum strap with Stab-Lock buckle.

Step 5: Reach between legs and grasp leg strap on your right side, bring strap up between legs and snap Stab-Lock buckle closed. Repeat for left side leg strap. Make certain leg web is not crossed or tangled, adjust strap to be snug.

Step 6: Adjust all buckles to be snug starting with leg straps, then shoulders and chest. Torso height can be adjusted with buckles located below sternum strap. Dorsal D ring should be adjusted to be located between shoulder blades below the neck on the back. Always adjust harness from the legs working up the harness.

Sharp Edges

Avoid working where the harness will be in contact with, or abrade against, unprotected or sharp edges. If working with this equipment near sharp edges is unavoidable, protection against cutting should be provided by using a heavy pad or other means over the exposed edge.

After a Fall

Harnesses which have been subject to the forces involved in arresting a fall must be removed from service.

Maintenance, Service, Storage

Before each use, inspect this harness to ensure that it is in a serviceable condition. Check for worn or damaged parts. Ensure all hardware (D rings, buckles, etc.) is present. Inspect to ensure that all buckles work properly and that they do not have any sharp edges, burrs, cracks or corrosion. Inspect webbing for wear, cuts, burns, frayed edges or other damage. Inspect all stitching for abrasion, discoloration and wear to ensure integrity. Store harness in a cool, dry, clean environment out of direct sunlight. Thoroughly inspect harness after any period of extended storage. Do not expose harness to flame or high temperature environments or excessive UV light. Avoid contact with any corrosive or caustic chemical agents such as acids, bases, or petroleum products. Discontinue use of product if it has come in contact with any of the above listed or any suspect chemical agents. Avoid storage and use of harness in areas where chemical vapors may exist. Discontinue use of harness and remove from service if inspection reveals an unsafe condition.

• This product has a life span of 10 years from time of production, must be properly maintained and must pass all inspection criteria.

Cleaning

Clean harness with warm water in a mild detergent solution. Wipe off hardware with clean, dry, cloth and hang to air dry. Do not force dry with heat.

Additional Information

Additional information regarding life safety harnesses can be found in NFPA 1500 and NFPA 1858 and NFPA 1983, incorporated in the 2022 edition of this standard.

ANSI/ASSP Z359.11 Safety Requirements for Full Body Harnesses and applicable regulations governing occupational safety.

Records

The user of this harness should keep a permanent record of the periodic inspections. Such record should show, as a minimum, inspection criteria as written in this document.

Use of this User Information Sheet

This user information sheet should be provided to and referenced by the user before use. Once separated from the harness, it should be retained and available to the user for the lifetime of the harness.

WARNING

No manufacturer can predict every potential hazard that exists with the use of any particular equipment. Yates Gear is not responsible for the mis-use of equipment or the negligence of end users. Training from competent, qualified trainers proven to be knowledgeable in its use is required prior to the use of this product.

- You could be killed or seriously injured if you do not read and understand the user information before using this equipment.
- This product is part of a personal protective, rescue or work support system.
- Special training and knowledge are required to use this equipment.
- You must thoroughly read and understand all manufacturer's instructions before use.
- You must read and follow the manufacturer's instructions for this product and each component of the complete system.

Stab-Lock Buckle System

To secure Stab-Lock buckle insert adjuster female end into non-adjuster male end of buckle. Insure buckle clicks. Pull free end of webbing on female adjuster side to adjust to desired fit.

To disconnect Stab-Lock buckle, press both ears located in center of buckle simultaneously.

WARNING!

WARNING: Keep buckle free of excessive dirt or dust. Buckle mechanism can be cleaned with compressed air or washed out with warm water and then blown dry with compressed air. Do not apply any oil or lubricant to buckle mechanism as this will attract dirt and dust and could make the buckle malfunction.









This harness is equipped with a visual indicator (fall arrest indicator) and label located just below the rear dorsal D-ring on the inside of the webbing that connects the rear of the chest to the rear of the seat portions of the harness. The label reads REMOVE FROM SERVICE! If this label is present after a fall occurs, this harness must be immediately removed and retired from service.

WARNING!

- Use and inspect this equipment only in accordance with these instructions.
- You are responsible for understanding the intended use of this harness, and the intended application and use of each of the multiple attachment points located on this harness.
- Only make compatible connections.
- Avoid sharp edges and abrasive surfaces.
- Ensure all fall protection systems incorporate appropriate anchorages.
- Do not alter this equipment in any way.
- Do not misuse this equipment in any way.
- Do not expose this equipment to harmful chemicals.

- Do not use this equipment around moving machinery, electrical hazards, sharp edges, or abrasive surfaces without competent analysis that the user is protected from potential harm.
- Never use combinations of components and subsystems that may affect or interfere with the safe function of this equipment.
- The user of this equipment should formulate a rescue plan and the means at hand to implement it when using this equipment.
- These manufacturer's instructions must be provided to the end user of this harness
- User must include harness stretch (6 inches), D ring/connector length and articulation, settling of the user's body and all other contributing elements in all clearance requirement calculations.

